



Daza Doorcontact

**1089-V2
(without switch)**

**1189-V2
(with switch)**

V 2024 – 1.1

QUICKSTART GUIDE

MOUNTING

We recommend mounting the door contact and the magnet using the double-sided tape that has already been applied. Alternatively, screws can also be used for installation. To do this, you will need to open the casing of the door contact (see *battery replacement*). Depending on the type of door frame, you may need to use the plastic magnet riser (see example photos).

To prevent the client from disabling the door contact themselves, it is preferable to mount it on the outside of the door.

The magnet can be mounted either to the left or right of the door contact.

It is important to ensure proper alignment. Use the *Installation Mode* (see *Installation Mode*) to determine the correct position for the magnet.

Fix the door contact and the magnet only after you are certain of their proper position and distance from each other.

Tip: First, remove a small section of the protective film from the double-sided tape. Temporarily attach the magnet and the door contact to the door and frame. You can now carefully test with the door open and closed to ensure the magnet is properly detected.



TURNING THE DOORCONTACT ON/OFF

The door contact works in conjunction with the Daza receiver and Pager. Ensure these devices are operational and, if necessary, connected to the nurse call system. Refer to the respective manuals for further details.

Activating the Door Contact:

- Activate the door contact when the door is closed (set the switch to position 1). A green LED will light up for 2 seconds (only for model 1189-V2). The system will now trigger an alarm when the door is opened. A red LED will flash, and an alarm notification will be sent.

Deactivating the Door Contact (only for 1189-V2):

- Deactivate the door contact before opening the door to enter the room (set the switch to position 0).
- If necessary, adjust the alarm settings on your nurse call system.

BATTERY REPLACEMENT

If the red LED briefly lights up every 2 seconds, this indicates that the battery needs to be replaced. For the version with a switch (1189-V2), the LED will light up red instead of green when activated. Additionally, during an alarm notification or supervision message, a low battery status will be sent, which can be viewed on the Daza Pager and receivers where the door contact is registered. Replace the battery with a 3.6-volt Lithium 2/3 A. **Daza article number: 7083.**

To open the door contact, carefully press one of the two tabs at the bottom behind the rounded section of the door contact using a small screwdriver. While doing this, try to tilt the front section upward. See photo. If needed, carefully press the second tab while maintaining pressure to tilt the cover. When inserting the new battery, ensure the positive (+) terminal is positioned at the top (see photo). To reassemble the door contact, hook the top section into place first.



INSTALLATION MODE

Follow the instructions below to activate installation mode:

1. Set the switch to position 1 (only applicable for item 1189-V2).
2. Hold the magnet against the contact as shown under the **MOUNTING** section.
3. Remove the magnet and place it on the opposite side. (A red LED will light up; you can ignore this.)
4. Repeat these steps once more. In total, you should hold the magnet against the door contact 2 times on the left and 2 times on the right.
5. The door contact should now be in *installation mode*. **Refer to the QR code for online instructions.**



In installation mode, the door contact will not send any alarms. This mode allows you to verify whether the magnet is correctly positioned. When the magnet is correctly positioned, the LED will light up green.

NOTE: To confirm proper magnet positioning, observe when the LED turns green **as the magnet approaches**. When the magnet is removed, the LED will remain green for a longer duration; this should not be mistaken for correct positioning.

Exiting Installation Mode:

1. Close the door so the magnet is detected by the contact. The green LED will light up.
2. After 10 seconds, the LED will turn off.
3. The door contact is now armed.
4. Open the door. The red LED will flash, and an alarm notification will be sent.

CLEANING AND DESINFECTION

Cleaning DAZA equipment is simple. There is no need to remove the batteries. Turn off the device to prevent triggering an alarm during cleaning. Use a damp cloth. If the device is very dirty, rinse the cloth as needed during cleaning. Afterward, let the device air-dry or dry it with a clean cloth.

You can safely use the following substances:

- Water
- Disinfectants such as chlorine 1000 ppm and chlorine 250 ppm
- 70% alcohol

Never use the following for cleaning:

- Bleach
- Harsh or corrosive cleaning agents
- Cleaning products containing ammonia or acetone

Apply your chosen cleaning agent to a cloth so that it becomes slightly damp. Do not spray or pour the cleaning solution directly onto the equipment. This prevents moisture from entering the device through small openings in the casing. Never submerge the product, wash it in a washing machine, or dry it in a tumble dryer. By following these cleaning instructions, you ensure the device remains in optimal condition.